

Diaphragms

1 month: Optional

Check for leaks with soapy water.

3 months: Optional

Check tightness of rear cover screws.

Spindle Services

1 month: Optional

Check bearing and collet actuation air pressure.

Check coolant flow and temperature.

12 months: Optional

Remove spindle from machine.

Replace diaphragms and exhaust silencer (if fitted).

Remove collet and inspect shaft taper for damage.

Check electrical terminations, wiring and screening for signs of damage.

For further information, please email: wwinfo@westwind-airbearings.com